




SETUP TIME/TEMP/DATE DISPLAY FREQUENCY (the rate at which your sign transitions between each screen).



- 2. Press + to increase the frequency value (the larger the number, the faster the transition)
 - Press to decrease the frequency value (the smaller the number, the slower the transition)
- 3. Press Enter to save the setting and exit the menu

Press **Esc** to cancel this operation and exit the menu

SETUP YOUR SIGN DISPLAY PREFERENCES (time format (12 hours or 24hours), temperature mode (Fahrenheit or Celcius) & time zone)

- 1. Press (Set) to begin editing the sign display preferences
- 2. Press the select time zone settings (the flashing number should be 0)

Display number 0 = time zone settings

- 1. Press 🕂 to display Eastern Time
- 2. Press 😑 to display Pacific Time
- 3. Press Enter to save the setting and exit the menu
- 4. Press (Esc) to cancel this operation and exit the menu



Display number 1 = temperature format (Celsius or Fahrenheit)

- 1. Press **Set** to begin editing the sign display preferences
- 2. Press Line 2 times to switch to temperature (the flashing number should be 1)
- 1. Press < to display Fahrenheit
- 2. Press (>) to display Celsius
- 3. Press Enter to save the setting and exit the menu
- 4. Press Esc to cancel this operation and exit the menu

Display number 2 = time format (12 hour or 24 hour)

- 1. Press **Set** to begin editing the sign display preferences
- 2. Press Line 3 times to switch to temperature (the flashing number should be 2)
- 1. Press < to display 12 hour time format * In 12 hour format
 - press Line to switch between A.M. and P.M.
- 2. Press (>> to display 24 hour time format
- 3. Press [Inter to save the setting and exit the menu
- 4. Press **Esc** to cancel this operation and exit the menu

SETUP AUTO AND MANUAL SCREEN DIMMING (changes the screen brightness settings)

- 1. Press (Set) to begin editing the sign display preferences
- 2. Press Line 4 times to switch to temperature (the flashing number should be 3)

Display number 3 = manual/auto dimming

- 1. Press Auto to setup auto dimming
 - press Hand to setup manual dimming
- 2. Press + to increase brightness (larger numbers are brighter)
- 3. Press to decrease brightness (smaller numbers are dimmer)
- 4. Press [Inter to save the setting and exit the menu
- 5. Press **Esc** to cancel this operation and exit the menu



CHANGE YOUR DISPLAY TIME SETTINGS

- 1. Press Time to start time setup (the selected digit will begin flashing)
- 2. Press + to increase selected time
- 3. Press to decrease selected time
- 4. Press () to select one digit to the right
- 3. Press < to select one digit to the left
- 3. Press Enter to save the setting and exit the menu
- 4. Press concel this operation and exit the menu

CHANGE YOUR DISPLAY DATE SETTINGS

- 1. Press **Esc** + + to setup the year (the selected digit will begin flashing)
 - Press (Esc) + (Time) to setup the date (the selected digit will begin flashing)
- 2. Press + to increase selected digit
- 3. Press 🔁 to decrease selected digit
- 4. Press () to select one digit to the right
- 3. Press < to select one digit to the left
- 3. Press Enter to save the setting and exit the menu
- 4. Press concel this operation and exit the menu

TOGGLE ON/OFF TIME, TEMPERATURE AND DATE

- 1. Press (Esc) to go into soft-off mode, then press (set) to begin setup
- 2. Press Line to select a function to toggle on/off

Number 0 = time

- 2. Press < to toggle off, press > to toggle on
- Number 1 = temperature
- 2. Press < to toggle off, press > to toggle on

Number 1 = date

- 2. Press **S** to toggle off, press **b** to toggle on
- 3. Press Enter to save the setting and exit the menu
- 4. Press Esc to cancel this operation and exit the menu



